



GB To be able to mount the float, first remove the transport rod and mount the float rod in its place.

ES Para poder montar el flotador, desmontar antes la varilla de transporte y en su lugar montar la del flotador.

FR Pour pouvoir monter le flotteur, retirez d'abord la tige de transport et montez la tige du flotteur à sa place.

